

NOTE: This kit is NOT to be used as a replacement seat. It is not safe for passengers to ride on the panel.

Removal of factory installed parts:

1. Remove the rear factory Mini trunk floor cover and the upper shelf cover from the car for easier access.
2. Remove the lower seat cushion by firmly pulling up on the front edge of the seat to release the clip on either side. Lift up and pull forward to remove the seat cushion from the car.
3. From the trunk area, fold both seat backs to the down position. The black plastic cover between the 2 seat halves must be removed to access the bolt underneath. Carefully lift up on the rear of the plastic cover and then wiggle it forward and backward to release the front of the plastic clip. It slides upward and off the car. →

NOTE: This plastic piece is easy to break especially in older cars that have caused it to get brittle with age.



4. ← Remove the now exposed single bolt. This allows you to remove the small metal bracket covering the seat pins.
You can optionally reinstall this black metal bracket once the seat backs are removed, so you don't lose the bracket if you choose to reinstall seats in the future.



5. Use a flat screwdriver to pry up and release the pin for the right side passenger seat back. Lean the seat back at about a 45 degree angle to the side panel, and pull away from the side panel, to release it from the car.
6. Repeat same procedure on left driver side seat back.

→



Seatbelt Removal (optional):

7. You can optionally remove the seatbelt components for additional weight loss and increased cargo space if you choose to do so, but it is not required.

Installation of Rear Seat Delete :

8. Install the included sound deadening pad in the lower seat area. It is pre-cut to fit around the seatbelt connectors. →



9. Use the included 4" x 5" black carpet material to cover the holes in the side panels on each side. It tucks under the edge of the plastic panels. →

**Installation of FOAM SUPPORT :**

10. If you purchased the extra option for expandable support foam, you will add it here at this step. It is not required, but adds additional weight handling and support for items placed on top of the rear seat delete.
11. Open the packaging for the expandable support foam bags and follow the instructions on the packaging.
12. You can also purchase this option from us separately if you did not get it with your original purchase.



14. Place the carpeted seat delete panel into the car. The raised carpet area on the top of the panel is to go over the metal bracket that is attached to the car floor.

NOTE: In the event that you need to adjust the height of this carpeted protrusion area for more clearance, it is simply attached with Velcro on the underside. You can reset the Velcro to a different position if needed.



15. There is no mounting hardware needed.

Your factory Mini rear panel reinstalls in the car over the rear lip of the seat delete panel, and holds it in place without the need for drilling holes or additional fasteners.

STORAGE TIP

16. The front edge of the panel can be lifted slightly to hide small items out of sight. Or if you have our additional support foam option, you will have the foam supports in this location which can be removed or added at any time.



Installation of Cargo Net :

18. There are 3 main configurations to hook your cargo net shown below.

SHRADER



19. To the upper seat mount brackets

(shown here with factory Mini trunk panel installed in lower down position for near-flat floor solution)



20. To the lower cargo hooks

(shown here with factory Mini trunk panel installed in upright position along with rear factory Mini shelf to hide the trunk area)



21. To the rearmost cargo hooks in trunk (boot)